



**SUBARU**

PART NUMBER: SOA3881250/SOA3881260

INSTALLATION  
INSTRUCTIONS


DESCRIPTION:  
SPT OIL CAP V2.1

**A**




SPT OIL CAP V2.1 X 1

**B**



INSTALLATION INSTRUCTIONS X 1

TOOLS REQUIRED



MEANING OF CHARACTERS

: Remove

**T** : Tighten Torque

: Install

: Loosen

: Disconnect

: Discard

: Connect

: Location of Clip or Screw

: Re use

PART NUMBER  
SOA3881250  
SOA3881260

ISSUE  
01


DATE  
02/15/11

SUBARU OF AMERICA

PAGE  
1/2



1: REMOVE OIL CAP



RE-USE



2: USE SCREWDRIVER TO REMOVE GASKET



3: INSTALL GASKET IN SPT OIL CAP



4: INSTALL SPT OIL CAP



**SUBARU**

NUMÉRO DE PIÈCE : SOA3881250/SOA3881260

INSTRUCTIONS  
D'INSTALLATION


DESCRIPTION :  
BOUCHON D'HUILE SPT V2.1

**A**




1 BOUCHON D'HUILE SPT V2.1

**B**



OUTILS REQUIS



1 INSTRUCTIONS D'INSTALLATION

SIGNIFICATION DES SYMBOLES

: Déposer

: Installer

: Déconnecter

: Connecter

: Emplacement de l'attache ou de

**T** : Couple de serrage

: Desserrer

: Jeter

: Réutiliser


NUMÉRO DE PIÈCE  
SOA3881250  
SOA3881260

VERSION  
01


DATE  
11-02-15

SUBARU OF AMERICA

PAGE  
1/2



1: ENLEVER LE BOUCHON D'HUILE




RÉUTILISER



2: UTILISER UN TOURNEVIS POUR ENLEVER LE JOINT



3: POSER LE JOINT DANS LE BOUCHON SPT



4: POSER LE BOUCHON D'HUILE SPT